

Budget X Banner Stand – Instructions




Step 1

Extend each of the arms with the hooks until you hear a click. That tells you the arms are in place.




Step 2

The center leg of the stand holds the stand in place. Drop the leg following the groove down until you hear a click.



Step 3

With your stand completely extended hook your graphic into the hooks with the hook part facing towards you, bending the arms a little bit to hold the graphic up.



*You can adjust the leg to open how deep you want to.

Applicable products

HIBSBXSS - HIBSBXSL

Support à Bannière Budget X – Instructions




Étape 1

Étendre chaque bras avec les crochets jusqu'à ce que vous entendiez un clic. Cela indique que les bras sont bien en place.



Étape 2

Le pied au centre garde le support en place. Descendre le pied au long de la rainure du support jusqu'à ce que vous entendiez un clic.



Étape 3

Lorsque votre support à bannière est complètement étendu, accrocher votre bannière dans les crochets de l'arrière. Au besoin, plier les bras un petit peu pour garder le graphique tendu.



**Si nécessaire, ajuster les pieds du support à bannière.*

Produits applicables

HIBSBXSS - HIBSBXSL