


## FabGraphics Pop Up Media Wall – Instructions




1. Lay pop-up on ground (fig. A-1) and pull straight up to expand (fig. A-2)
2. Interlock steel hooks to hold frames securely in place (fig. B)
3. Attach graphic to velcro perimeter (fig. C)
4. Attach end panel bracket to frame using flat-head screw (fig. D)
5. Wrap graphic around the end panel (fig. E)
6. To replace a steel hook, unscrew and remove nut and X bracket. By leaving the screw intact, replace the X bracket and re-tighten the nut (fig. F)

### Applicable products

HITDPFK22-T - HITDPFK22EC-T - HITDPFK23-T - HITDPFK23EC-T - HITDPFK32-T - HITDPFK32EC-T - HITDPFK33-T - HITDPFK33EC-T - HITDPFK33C-T - HITDPFK33CEC-T  
 HITDPFK43-T - HITDPFK43EC-T - HITDPFK43C-T - HITDPFK43CEC-T - HITDPFK44-T - HITDPFK44EC-T - HITDPFK53-T - HITDPFK53EC-T - HITDPFK54-T - HITDPFK54EC-T  
 HITDPFK63-T - HITDPFK63EC-T - HITDPFK64-T - HITDPFK64EC-T - HITDPFK73-T - HITDPFK73EC-T - HITDPFK83-T - HITDPFK83EC-T - HITDPFK84-T - HITDPFK84EC-T

# Mur de Média Pop Up FabGraphics – Instructions



1. Poser le cadre pop-up sur le plancher (fig. A-1) et soulevez-le vers le haut pour l'élargir (fig. A-2)
2. Verrouiller les crochets en acier pour garder le cadre fermement en place (fig. B)
3. Attacher le graphique au velcro au périmètre du cadre (fig. C)
4. Attacher un support sur l'arrière du cadre à l'aide d'un tournevis plat (fig. D)
5. Envelopper le graphique autour du côté du cadre jusqu'au support sur le côté arrière (fig. E)
6. Pour remplacer un crochet, dévisser la vis, enlever l'écrou et le support en X. Tout en laissant la vis intact, remplacer le support en X et revisser l'écrou (fig. F)

## Produits applicables

HITDPFK22-T - HITDPFK22EC-T - HITDPFK23-T - HITDPFK23EC-T - HITDPFK32-T - HITDPFK32EC-T - HITDPFK33-T - HITDPFK33EC-T - HITDPFK33C-T - HITDPFK33CEC-T  
 HITDPFK43-T - HITDPFK43EC-T - HITDPFK43C-T - HITDPFK43CEC-T - HITDPFK44-T - HITDPFK44EC-T - HITDPFK53-T - HITDPFK53EC-T - HITDPFK54-T - HITDPFK54EC-T  
 HITDPFK63-T - HITDPFK63EC-T - HITDPFK64-T - HITDPFK64EC-T - HITDPFK73-T - HITDPFK73EC-T - HITDPFK83-T - HITDPFK83EC-T - HITDPFK84-T - HITDPFK84EC-T